

## AL200 Combination Cam Lock – User Instructions



### Setting Your Own Combination:

1. The combination is factory set at all 0's.
2. Combination must be on opening number prior to resetting.
3. BEFORE SELECTING YOUR NEW CODE – WRITE IT DOWN
4. On the side of the lock is code reset button. Press and hold down code reset button while you set your personal combination by turning dials to desired combination.
5. Release reset button and your combination is set. To lock, turn knob to put cam in closed position and rotate one or more dials to lock. Test your combination with the door in the open position first.
  6. To open lock, turn dials to your personal combination and rotate knob counter-clockwise.

### Unlocking Cam Lock Using Key:

Insert key into lock, rotate key counter clockwise to unlock symbol

### Discovering Combination Using Key:

Open with the Master Key to unlocked position. Whilst in unlocked position turn each dial until it stops. Repeat this on all dials, and once they have stopped, the combination has been discovered.

### Resetting a lost or forgotten Code:

Open with the Master Key to unlocked position. Whilst in unlocked position turn each dial until it stops. Repeat this on all dials, and once they have stopped, the combination has been discovered.

Once the previous combination has been discovered, follow the steps of setting user code:

1. Please note that the combination must be on opening number prior to resetting.
2. BEFORE SELECTING YOUR NEW CODE – WRITE IT DOWN
3. On the side of the lock is code reset button. Press and hold down code reset button while you set your personal combination by turning dials to desired combination.
4. Release reset button and your combination is set. To lock, turn knob to put cam in closed position and rotate one or more dials to lock. Test your combination with the door in the open position first.
5. To open lock, turn dials to your personal combination and rotate knob counter-clockwise.